



## **OLS12A Campsite Locator Beacon System**

*Thank you for choosing CYRON products! At CYRON we are committed to provide the latest lighting technology without any compromises.*

Please read all instructions and follow carefully. Should you need help you may contact CYRON customer support at 818-772-1900 x106 or customer@cyron.com. Alternatively, you may seek assistance from an authorized CYRON dealer near you.

### **COMPONENTS:**

- |   |                         |  |
|---|-------------------------|--|
| 1 x Light stick                                 | 1 x Controller box      | 1 x Remote control key fob             |
| 1 x Extension cord, 25ft                        | 1 x Flagpole mount stud | 1 x Through-hole mount screw, 3/8 x 1" |
| 1 x Velcro strap (packaged with extension cord) |                         |  |

### **TOOLS NEEDED:**




None

### **OVERVIEW:**

CYRON OLS12A Campsite Locator Beacon Light is primarily used for locating and differentiating your campsite. It emits light in various colors & patterns to visually identify you and your location from others. Its visual signal can be identified from miles away<sup>1</sup>. Flashing light modes can be a perfect tool for relaying a visual message, such as flashing red for emergencies, green for call back to camp, or blue for when the meal is being served. Make your own designations, have fun, and stay safe.



### **CAUTIONS:**



- Keep controller in dry location.
- Do not attach flags, streamers or any other objects to the light stick.
- Do not put extra force on clear lens or attempt to bend.
- Do not over tighten the mounting bolts and studs.
- Remove light before vehicle is underway.
- Not intended for use as an off road whip light.
- Do not submerge any part of this lighting system.
- **STOP** Do not use during lightning storm. Extreme chance of injury and electrocution.


### **INSTRUCTIONS:**

- 1. Connect Wires:** CYRON Campsite Locator Light Beacon is provided with a 25ft extension cord. It should be long enough to reach the top of most all flagpoles which are normally 22ft or less. Should longer cords be needed, extra extension cords are available from CYRON, Inc. or your local CYRON dealer.

Connect light stick to extension cord. Press male & female ends completely together. Thread the retainer ring. Do not over tighten. Connect other end of extension cord to the controller.

- 2. Mount Light Stick:** Mount the light stick using the flagpole stud or through hole bolt. Do not over tighten.

- 3. Secure Wire:** Secure wire at the top of flagpole with Velcro strap provided. **NOTE:** The strap is packaged with the extension cord. This will provide a security should the light stick fall out for any reason. Remove the light stick during extreme foul weather, thunderstorms or tornados. When mounting on a flagpole, wrap the wire around the pole three turns to minimize slack in the wire.



- 4. Power source:** Connect controller to a 12VDC source. You may choose to leave controller permanently connected to one the batteries on your vehicle. In such case it is highly recommended to remove the fuse from fuse holder when CYRON system is not being used. Keep controller in dry location.



Attach a small magnet to the back of the controller so you can simply place it on the underside of your trailer or coach in case of rain. Don't forget to remove before you get on the road!

**5. Remote functions:**

- On/Off:** Turn beacon light on & off
- Modes:** Cycles through various light modes. Take a moment and cycle through all the modes to familiarize yourself with the sequence.
- Pause:** Stop the light on any color you like during “Color Transition Modes”

CYRON OLS12A system is equipped with 3 flashing modes. Flashing lights can be a perfect tool for relaying a visual message, such as flashing red for emergencies, flashing green for call back to camp, or flashing blue for when the meal is being served. Make your own designations, have fun, and stay safe.

**WARRANTY**

Cyron warrants this product against any defects in materials or workmanship for a period of ONE (1) year from the date of purchase. The warranty covers normal usage as intended by the factory and does not cover misuse, abuse, accidents, or damages caused due to the acts of God. Proof of purchase is required.

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL CYRON, INC. BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Please mail all warranty claims to:  
 CYRON, Inc.  
 OLS Warranty Claim  
 9439 Irondale Ave.  
 Chatsworth, CA 91311 USA

Further warranty inquiries: [warranty@cyron.com](mailto:warranty@cyron.com)



**Laws concerning additional lights on a vehicle vary in different regions. Consult your local authorities regarding the regulations.**

**Other quality automotive lighting accessories & upgrades available from CYRON**

For details please contact your local dealer or inquire at [www.CYRON.com](http://www.CYRON.com):



<u>Part Number</u>	<u>Description/Application</u>
<u>OLS12A system accessories</u>	
OLSRB-10	10ft waterproof multicolor outdoor ribbon light, Compatible with OLS12A system
OLB2	2ft Lightbar for OLS system, Light stick only
OLS-Y2	Y connector for OLS12A system, used for adding multiple lighting devices to one controller
CON-4CSET	25ft extension cord for OLS12A
<u>Other automotive parts &amp; accessories</u>	
MLKP7C-[color]	Accent Lighting Kit, Platinum, Remote Control with 7xCV6 chrome lights
MLKG4C-[color]	Accent Lighting Kit, Gold, Remote Control with 4xCV6 chrome lights
CV62C-[color]	Convex 6LED Cluster, Chrome finish PAIR
CV62-[color]	Convex 6LED Cluster, Black finish PAIR
FL30-[color]	PRO SERIES – FlexLED super flexible strips, 30LED, 12”
FL24-[color]	PRO SERIES – FlexLED super flexible strips, 24LED, 10”
FL18-[color]	PRO SERIES – FlexLED super flexible strips, 18LED, 7”
CMF1202	Rigid mount for FlexLED, 10”, perfect for ground effect and light under saddle bags
CON-TB005	Solder-less Terminal Block, 5 outlet
AB1156D-24	Light bulb, 24LED 1156 single contact, Amber OR Red
AB1157D-24	Light bulb, 24LED 1157 dual contact, Amber OR Red
AB3156D-24	Light bulb, 24LED 3156 single contact, Amber OR Red
AB3157D-24	Light bulb, 24LED 3157 dual contact, Amber OR Red
RC2-12	Wireless remote control, On-Off, 2 remotes, 12VDC, 20A max rating
RC50-12	Multi-zone or RGB 3 channel wireless remote control, 3x4A
MK08-6	Multicolor Lighting Kit, 6x8” lightbars, Multi function remote control
MK12-6	Multicolor Lighting Kit, 6x12” lightbars, Multi function remote control
BL102	Automatic Bag Lights, PAIR

1. Visual distance depends on variables such as air clarity, obstacles, elevation from the ground and many others.
2. This device is not meant to replace a navigation device. Always use common sense to identify your location.